


Round jaws for accurate ID measurement

Long Jaw Vernier Caliper **SERIES 534**

- Long jaws for measuring hard-to-reach workpiece features.
- Inside and outside measurements can be read directly from the upper and lower vernier scales.
- Inside measurement is possible upwards from the minimum inside measuring length (jaws closed).



SPECIFICATIONS

Metric _____ with inside measurement vernier scale

Order No.	Range (mm)*1	Graduation (mm)	Maximum permissible error (mm)* ² EMPE SMPE		Remarks
534-109	0 (10.1) - 300	0.05	±0.07	±0.07	without fine adjustment
534-110	0 (20.1) - 500	0.05	±0.13	±0.13	without line adjustment

*1 (): Minimum dimension in ID measurement *2 Partial Surface Contact Error, *E*MPE and Shift Error, *S*MPE are terms (notations) used in ISO 13385-1:2019.

Metric/Inch with metric/inch double scale

incure/incire - with incire double scale							
Order No.	Range (mm)* ¹	Graduation	Maximum permissible error (mm)*2		Remarks		
Order No.	Nange (mm)	Graduation	Empe	Smpe	Remarks		
534-101	0 (10.1) - 300	0.05 mm/1/128 in	±0.07	±0.07	+10 mm/0.394 in to reading in inside		
534-105	0(10.1)-300	0.02 mm/0.001 in	±0.04	±0.04	measurement without fine adjustment		
534-102	0 (20.1) - 500	0.05 mm/1/128 in	±0.13	±0.13			
534-106	0 (20.1) - 300	0.02 mm/0.001 in	±0.06	±0.06			
534-103	0 (20 1) 750	0.05 mm/1/128 in	±0.16	±0.16	+20 mm/0.787 in to reading in inside		
534-107	0 (20.1) - 750	0.02 mm/0.001 in	±0.08	±0.08	measurement without fine adjustment		
534-104	0 (20.1) - 1000	0.05 mm/1/128 in	±0.20	±0.20			
534-108	0 (20.1) - 1000	0.02 mm/0.001 in	±0.10	±0.10			

*1 (): Minimum dimension in ID measurement *2 Partial Surface Contact Error, *Емре* and Shift Error, *Sмре* are terms (notations) used in ISO 13385-1:2019. Note: For external dimensions, refer to the **series 534** on page D-23.




Calipers An industry standard measuring tool

Long Jaw Vernier Caliper SERIES 534

- Long jaws for measuring hard-to-reach workpiece features.
- Inside and outside measurements can be read directly from the upper and lower vernier scales.
- The fine-adjustment wheel enables precise feed and adjustment.
- Inside measurement is possible upwards from the minimum inside measuring length (jaws closed).

	e		
Mitutoyo		er 19 12 20 01 10 20 01 10 20 04 00 00 07 20 20 00 01 00 00 00 00 00 00 07 20 00 00 01 00 40 40 40 40 40 40 40 40 40 40 40	
	0 0 0 0		
The second			
		Fine-adjustment wheel	
		,	
		534-114	
100			
	1		
	ſ		





Radiused jaws for accurate ID measurement

SPECIFICATIONS

Metric with inside measurement vernier scale

Order No.	Range (mm)* ¹	Graduation (mm)	Maximum permis	sible error (mm)* ²	Remarks
Order No.			Empe	Smpe	Remarks
534-113	0 (10.1) - 300	0.02	±0.04	±0.04	
534-114	0 (20.1) - 500		±0.06	±0.06	with fine adjustment
534-115	0 (20.1) - 750		±0.08	±0.08	with the adjustment
534-116	0 (20.1) - 1000		±0.10	±0.10	

*1 (): Minimum dimension in ID measurement

*2 Partial Surface Contact Error, EMPE and Shift Error, SMPE are terms (notations) used in ISO 13385-1:2019.

Inch with inside measurement vernier scale							
Order No.	Order No. Range (in)* ¹ Graduation (in)		Maximum permissible error (in)*2			Remarks	
order No.		Graduation (in)	Empe	Smpe		Nethal K5	
534-117	0 (0.304) - 12	0.001	±0.002	±0.002			
534-118	0 (0.804) - 20		±0.003	±0.003		with fine adjustment	
534-119	0 (0.804) - 30		±0.004	±0.004		with the adjustment	
534-120	0 (0.804) - 40		±0.004	±0.004			

*1 (): Minimum dimension in ID measurement

*2 Partial Surface Contact Error, EMPE and Shift Error, SMPE are terms (notations) used in ISO 13385-1:2019.

DIMENSIONS

